

## **Top Ten Tips for Cold Weather Tile Installation**

When working in cold weather, it is important to consider four key temperatures: water temperature, powder temperature, ambient temperature, and surface temperatures. Low temperatures for any of these four parameters can inhibit a product's cure. Once a critically low temperature is reached, the cement curing reaction stops, which can cause jobsite failures.



